



Integration Note

Manufacturer:	Xantech Corporation
Model Number(s):	HD88C, HD88CC5
Core Module Version:	5.7 (g!)
Document Revision Date:	1/25/2013

OVERVIEW AND SUPPORTED FEATURES

The Xantech HD88C and HD88CC5 are 8 X 8 Component Video Controllers which switch eight component sources to any of eight component outputs and can be controlled by the **g!** software with an RS-232 serial connection to allow reliable 2-way communication. Up to four HD88Cs or HD88CC5s can be stacked for a total of 32 zone outputs from eight source inputs.

THE FOLLOWING FEATURES ARE SUPPORTED:

Multiple Chassis Configuration: Up to four HD88C/HD88CC5s can be linked together to provide 32 zone outputs from eight source inputs. Refer to the HD88C/HD88CC5 installation manual for inter-chassis connections.

THE FOLLOWING FEATURES ARE NOT SUPPORTED:

Control from HomeBrick/MultiBrick: The HD88C and HD88CC5 cannot be controlled from HomeBrick/MultiBrick controllers.

Audio Control: The HD88C and HD88CC5 can route digital audio using their SPDIF connections, however, volume, DSP setting, etc., functions are not present in the HD88C/HD88CC5 chassis and therefore can't be controlled by the **g!** system.

Any feature not specifically noted as supported should be assumed to be unsupported.
--

INSTALLATION OVERVIEW


1. During the rough-in phase, install wires for the sources, amplifiers and displays for each zone.
2. Also during the rough-in phase, run a Cat5 wire from the location of the switch back to the HCxx controller for RS-232 communications. Refer to the *HCxx Installation Manual* for the RS-232 wiring code.
3. Install the switch, the sources, amplifier, displays and speakers.
4. Confirm proper video switching as a stand alone system.
5. Connect the **g!** system to the switch electrically. See the wiring diagrams for more information.
6. Configure the **g!** system for the switch and confirm communication between the switch and the Controller.
7. Test the system by changing sources in a zone to confirm the correct source plays. Test source control for any sources that are to be controlled from the **g!** interface.

ELAN Home Systems • 1690 Corporate Circle • Petaluma, CA 94954 USA

tech support: 800.622.3526 • main: 760.710.0990 • sales: 877.289.3526 • email: elan@elanhomesystems.com

©2013 ELAN Home Systems. All rights reserved. ELAN and g! are trademarks of ELAN Home Systems. All other trademarks are the property of their respective owners.

CONNECTION DIAGRAM



BILL OF MATERIALS

#	Device	Manufacturer	Part #	Protocol	Connector Type	Notes
1	HCxx Controller	ELAN	HCxx	RS-232	RJ-45 Female	
2	Cat5 Cable	Installer	N/A	568A or 568B	RJ-45 Male	
3	DB9M RJ-45 Adapter	ELAN	HA-CB-307	RS-232	DB9 Male x RJ-45 Female	
4	Component Video Cable	N/A	N/A	Analog	RCA x RCA	

g! CONFIGURATION DETAILS

The following table provides settings used in the **g!** Configurator. Please refer to the ***g!** Configurator Reference Guide* for more details.

In the table below:

- "<Select>" Select the appropriate item from the list (or drop-down) in the Configurator.
- "<User Defined>", etc. Type in the desired name for the item.

Devices	Variable Name	Setting	Comments
Communication Device	Name	<User Defined> (Default: Xantech HD88CC5 (1-4 Units))	
	Type	Serial Port	
	Communication Type	Standard Connection	
	Location	<User Defined> (Not Required)	
	Comm Port	<Select>	
<Other RS-232 Sources> Add any other RS-232 controlled sources. Refer to the Integration Note for each specific source device.			
<Other IR Controlled Sources: Add IR devices on the Input/Output tab for other IR controlled sources. Refer to the Configurator Reference Guide			
Other Devices / Interfaces	Name	<User Defined>	Add Interfaces for any source that does not have a builtin interface.
	Template	<Select>	
	Default Device	<Select>	Select the RS-232 or IR Controlled source for this interface.
Audio Zone Controllers	Name	<User Defined> (Default: Xantech HD88CC5 (1-4 Units))	Use Number of Units drop down to change the number of chassis in the system.
	Device Type	Xantech HD88CC5 (1-4 Units)	
	Location	<User Defined> (Not Required)	
	Comm Device	<Select>	
Sources	Name	<User Defined>	
	Source Device	<Select>	Sources must be previously configured to allow selection.
	Source Volume	<Select>	N/A
	Show Source	<Select>	Set to NO for any inputs that are not used.
	Source Icon	<Select>	This icon zppears on the source button for the viewer interface.
	Display Name	<User Defined>	This text zppears on the source button for the viewer interface.
Zones	Name	<User Defined>	
	Universal Receiver	<Select>	
	Display	<Select>	
	Configuration Interface	<Select>	
	<Sources List>	<N/A>	
Tab Layout	Interface Tabs	<Select>	Move any unused zones to the left into Available Zones to remove from the viewer.

COMMON MISTAKES

1. Failure to connect Source video loops between HD88C/HD88CC5 chassis.
2. Failure to set the Chassis ID dip switches correctly on the HD88C/HD88CC5 chassis.