








Applicaton: Provides power and ViaNet to and IR from four TS2s.

Connects to the ViaNet port on a rack mounted Home Controller or to the ViaNet punchdown of a PPCM when using can mounted controllers.

- **Location:** Head-end
- Wiring Basics: Cat5 connects to TS2s located in zones as well as to additional PPVNs and/or PPCM. Cat5 jumper from RJ-45 to PPWM.







P/N 9901048 Rev. B - 5/03/10 INSTR, INSTL, PPVN LINEAR P/N 9901048 REV: B INK: BLACK MATERIAL: 60 LB WHITE PAPER No. PAGES: 2 Pages (Front and Back) SCALE: 1-1 SIZE: 17.0 × 11.0 SIZE: 17.0 × 11.0 FOLDING: SEE ARTWORK • "PPVN" SHOWS ON FRONT Final Dimension: 4.25 × 2.75 NOTE: ARTWORK CREATED BY ELAN HOME SYSTEMS THIS MANUAL MUST BE ROHS COMPLIANT

